

HOW TO RUN DTMF_SEND_SS.ino example

- a. Make a folder named DTMF_SEND_SS
- b. copy and paste the code into a file named DTMF_SEND_SS.ino and save it into the previous created folder,
or,
copy the file DTMF_SEND_SS.ino into the previous created folder
- c. download (**) the "a-gsm kickstart for Arduino (COMPILABLE) CODE - version 0.9711/2016.07.15" from:
<https://itbrainpower.net/a-gsm/gsm-shield-Arduino-RaspberryPI-features-code-examples>
or from:
<https://itbrainpower.net/downloads>
- e. Expand (de-compress) the dowloaded "a-gsm kickstart for Arduino".
- f. Copy following files into the DTMF_SEND_SS folder: "agsm_basic_lbr.h", "agsm_DTMF_lbr.ino" and "agsm_basic_lbr.h", "agsm_DTMF_lbr.ino"
- g. Open DTMF_SEND_SS.ino into the Arduino environment and edit "destinationNumber" and other variables found at lines 41==>46. Compile, upload. Enjoy!

ARDUINO Serial Monitor speed: 57600bps

** For "a-gsm kickstart for Arduino" download, your name, email address and the modem IMEI are requiered.

The modem IMEI can be found printed on the Quectel GSM module, or run AT+GMGS command.