

how2run-DTMF\_RECEIVE\_SS\_ino.txt

HOW TO RUN DTMF\_RECEIVE\_SS.ino example

a. Make a folder named DTMF\_RECEIVE\_SS

b. copy and paste the code into a file named DTMF\_RECEIVE\_SS.ino and save it into the previous created folder,

or,

copy the file DTMF\_RECEIVE\_SS.ino into the previous created folder

c. download (\*\*) the "a-gsmII/b-gsmgnss kickstart for Arduino (COMPILABLE) CODE - version 0.9711" from:

<https://itbrainpower.net/downloads#a-gsmII>

or

<https://itbrainpower.net/downloads#b-gsmgnss>

e. Expand (de-compress) the downloaded "a-gsmII/b-gsmgnss kickstart for Arduino".

f. Copy following files into the DTMF\_RECEIVE\_SS folder:

"agsmII\_basic\_lbr.h", "agsmII\_DTMF\_lbr.ino" and "agsmII\_basic\_lbr.h",  
"agsmII\_DTMF\_lbr.ino"

or,

"bgsmgnss\_basic\_lbr.h", "bgsmgnss\_DTMF\_lbr.ino" and "bgsmgnss\_basic\_lbr.h",  
"bgsmgnss\_DTMF\_lbr.ino"

g. Open DTMF\_RECEIVE\_SS.ino into the Arduino environment and edit

"destinationNumber" and other

variables found at lines 40==>41. Compile, upload. Enjoy!

ARDUINO Serial Monitor speed: 57600bps

\*\* For "a-gsmII/b-gsmgnss kickstart for Arduino" download, your name, email address and the modem IMEI are required.

The modem IMEI can be found printed on the Quectel GSM module, or run AT+GMGS command.